


How Solar Attic Fans Work




Heat from the sun causes Super High Attic Temps

Solar Attic Fans Continuously Exchange Attic Air to Cool Attic



Over-heated ductwork

Cooler ductwork



worked system



Attic Heat Radiates Down into Living Spaces Causing Discomfort


Before Installing Solar Attic Fans



Your Living Areas are Cooler with Less HVAC Use

After Installing Solar Attic Fans

Cooler Air Pulled in



Efficient System